

Assembly Guide

For assembly, wood glue needs to be added on all the dadoed/grooved lines.

Wood dowels should be on cabinets, if not the wood dowels should already be pre-drilled to only put in the wood dowels.

The pocket screws are for temporary holding while the glue dries up.

The glue is the main strength to hold the cabinets together.

